

**MOOER**

**PRIME P1  
INTELLIGENT PEDAL**

**Owner's Manual**

# Content

Precautions-----	01
Features-----	02
Layout-----	03-04
Instructions-----	05-06
Connection-----	07-08
Specification-----	09

# Precautions

## PLEASE READ CAREFULLY BEFORE PROCEEDING

### Power Supply

- Please use a power supply that meets UL, CSA, VED, or CCC standards
- Please use the power supply that meets manufacturer's power requirement
- Please unplug the power supply when the device is turned off or during a thunderstorm
- Please do not expose the device which has battery power to heat or let it overheat
- If battery leakage occurs, please do not touch the liquid with your skin or eye. If you do come in contact, please see a doctor
- The battery included with the device may cause fire or chemical burns if handled improperly

### Location

To avoid deformation, discoloration, or other serious damage, do not expose this unit to the following conditions:

- Direct sunlight
- Excessive dusty or dirty location
- High humidity or moisture
- Extreme temperature or humidity
- Magnetic fields
- Strong vibrations or shocks

### Cleaning


Clean only with a soft, dry cloth. If necessary, slightly moisten the cloth. Do not use abrasive cleanser, cleaning alcohol, paint

## Features

- Eliminates the need to carry a massive power supply or deal with complicated user interfaces. Simply set up your effects chain and jump into your practice session or performance.
- Based on MOOER's unique MNRS technology, allowing for high-quality digital amp models and effects with a small form factor.
- Supports USB-OTG for live streaming or quick video recording.
- Download the free mobile app to easily edit your tones and share them with others as well as download different effects modules and tools to expand your own tonal possibilities
- Supports MOOER F-series wireless footswitches for preset switching and looper/drum machine control.
- Bluetooth audio playback for practice and jamming.



# Layout



## **01. CONTROL**

Control Knob with LED indicator. Rotate to adjust volume level. Press to switch between different preset patches.

## **02. INPUT**

Input jack for instruments

## **03. OUTPUT**

Output jack for main output

## **04. PHONES**

Headphone output jack

## **05. USB**

USB charging/OTG port

## **06. LED**

Charging Indicator

# Instructions

## **01. ON/OFF**

Press and hold the Control button to power on/off the unit. The button LED will be turned on or off to indicate current status..

## **02. Select Preset Tone**

Press the CONTROL knob to switch between A/B/C/D preset patches. The LED of the CONTROL knob will turn Blue/Green/Yellow/Red to indicate the selected preset.

## **03. Adjust Output Volume Level**

When the device is on, rotate the CONTROL knob to adjust the output level of the unit. The brightness of the LED will indicate the volume level, with brighter corresponding to a higher volume level.

## **04. Bluetooth Playback**

Turn on the Bluetooth function of your phone and select "Prime Audio" to pair. You can then play the audio track from your phone with the Prime P1 directly.

## **05. USB Audio**

Prime P1 support OTG function to work with smart phone/tablet for direct recording.

\*Notes: Please use USB-C to USB-A cable for OTG recording.

## **06. Charging**

Prime P1 has a built-in rechargeable lithium-ion battery. When the battery life is low, the LED of the CONTROL knob will blink slowly. The Prime P1 supports charging via smart phone adaptor/power bank/USB port of computer. While charging, the charging indicator will turn on with Red indicating charging and Green to indicate charging complete.

\*Notes: Please use USB-C to USB-A cable to charge.

## **07. Wireless Footswitch (Purchase separately)**


Prime P1 supports MOOER F-series wireless footswitch. Users can utilize the wireless footswitch to control many functions of the unit. Before using the wireless footswitch for the first time, you must pair it with the Prime P1. Please check out the " ? " on the Prime App home page on pairing under "Pedal Connection"

## **08. Prime App**


Users can download and install the Prime App to their mobile device from the Google Play/iOS application store. Users can edit preset patches, share tones with other users, or use the built-in tools such as tuner/drum machine/metronome/looper. Apart from that, you can download and install different effects modules in the Prime App and apply them to your P1. For more information, please download and install the Prime App.

# Connection

## Normal



## USB Recording



## Specifications

<b>Input:</b>	1/4" 2 M $\Omega$
<b>Output:</b>	1/4" 100 $\Omega$
<b>Headphone output:</b>	1/8" 32 $\Omega$
<b>USB cable type:</b>	USB-C to USB-A cable
<b>Bluetooth version:</b>	5.0
<b>Battery Capacity:</b>	1900mAh
<b>Battery Life:</b>	4.5 hours
<b>Charging Requirement:</b>	DC 5V/1A
<b>Wireless Control:</b>	2.4G
<b>Weight:</b>	100g
<b>Dimensions:</b>	99.3mm (D) * 55mm (W) * 21mm (H)
<b>Accessories:</b>	Quick guide, USB-C to USB-A cable, Nylon bag.

**\*Disclaimer: Parameter updates will not be notified separately.**

**MOOER**  
[www.moeraudio.com](http://www.moeraudio.com)

---

SHENZHEN MOOER AUDIO CO. LTD  
6F, Unit D, Jinghang Building, Liuxian 3rd Road,  
Bao'an 71 District, Shenzhen, China. 518133  
Made in China