

Pearl malletSTATION™



Installation Instructions for *PreSonus Studio One 4 Artist* and the Included *Pearl malletSTATION Sound Set*


Step 1 – Visit www.pearlmalletstation.com to register and receive your Product Key for *PreSonus Studio One 4 Artist* and to download the *Pearl malletSTATION Sound Set*. Click the Log In Button to get to the registration screen.




Step 2 – Choose a username, email, and password, as well as enter your malletSTATION serial number (found on the bottom of the unit, or on the box).

A registration form with a dark blue background. At the top left, the word "Register" is written in red. Below it are four white input fields stacked vertically. The first field is labeled "Username", the second "Email", the third "Password", and the fourth "malletSTATION Serial Number (EMXXXXXXXX)". At the bottom left of the form is a red rounded rectangular button with the word "Register" in white.


Step 3- Once you're in your My Account screen, you'll see the following. Click on the Downloads tab on the left-hand side.



Step 4- Once at the downloads screen, you'll see the following information - Your malletSTATION Serial number, your *Presonus Studio One 4 Artist* Product Key, the installation instructions for *Studio One*, and the download for the *Pearl malletSTATION SoundSet* for *Studio One 4 Artist*. Write down/save your Presonus Product Key and download the *Pearl malletSTATION Sound Set*.



Step 5 – Once you have your *Presonus Studio One 4 Artist* Product Key, visit my.presonus.com and create a free user account.




The screenshot shows the My.PreSonus website interface. On the left, a login box for returning customers includes a message: "You've logged in with your PreSonus username or email in the past. Please login below." It features a "Returning Customer" heading, a prompt to "Please login with your email/username and password below," and input fields for "Email or username..." and "Password...". A "Login" button is present, along with a "Remember Me" checkbox and a "Forgot your password?" link. On the right, a section titled "Don't have a My.PreSonus account yet? Here's why you should sign up." lists three benefits with icons: 1. Access to product info, upgrades, training videos, and special offers. 2. Eligibility for technical support, updates, and warranty service. 3. Access to a community forum and blogs. A "Create My.PreSonus Account" button is located at the bottom right.

Step 6 – Once logged into your My Presonus account, click “Register a Product”.



Step 7 – Choose Product Type “Software”, and then enter your *Studio One 4 Artist* Product Key received in Step 1 into the Window. Accept the EULA by checking the box and then click Register.



The screenshot shows a "Register Product" dialog box. At the top, there is a dropdown menu currently set to "Software or Extensions". Below this, the text "Enter a product key." is followed by instructions: "Keys can be either 20 or 28 characters. If you have a 28 character key, keep typing when the spaces run out and more will appear." A text input field for the product key is provided. Below the input field, there are two checkboxes: the first is "I have read and agree to the terms in the End User License Agreement." and the second is "I would like to receive emails from PreSonus with product related information." At the bottom of the dialog, there are "Close" and "Register" buttons.

Step 8 – Download and install the correct version of *Studio One 4 Artist* for your device (Mac or PC) by following the instructions on the [my.presonus.com](https://www.presonus.com) website.



Studio One 4 Artist OEM
v4.0.1 build 48247
Product Key
[Redacted]
Vendor: Pearl
[Upgrade](#) • [Offline Activation](#) • Registered: Jul 12th, 2018 • [Transfer License](#) • 0 of 5 Activations

To install this software...

Step 1: Download the installer. Once the download has completed, locate and double click the installer file to start installation, and follow the onscreen instructions.

[Download Installer - Windows \(64 bit\)](#)


[Studio One 4 for Windows](#)

[View Other Systems](#)

[View Previous Versions](#)

[View Release Notes](#)

Step 9 – Once installed, open the *Studio One 4 Artist* application and activate the purchased version using the Product Key and email address found in your My Presonus account.



Studio One Activation



Welcome! To authorize this computer for the use of Studio One, please select your version and activate it below.

☒ Activate my purchased version of Studio One
☐ Try the full version for a time limited demo period
☐ Run Studio One Prime - the feature limited FREE version


Product Key

☐ I have purchased an upgrade of Studio One



[Activate](#)

No Internet connection? [Activate Offline](#)


Step 10 – Once you're at the Start Screen, drag the *Pearl malletSTATION Sound Set* file you downloaded in Step 1 anywhere into the *Studio One* Start Screen. The file will change into the "Install Sound Set" graphic shown in the below image. Let go of the file and it will automatically install in the correct location on your computer.



Step 11 – Click "Create New Song" in the Start Screen to open the template list. Once open, choose the "Pearl malletSTATION Template".



Step 12 – At this point, both *Presonus Studio One 4 Artist* and the *Pearl malletSTATION Sound Set* are installed. Plug your malletSTATION into your computer, and you should then be able to select a track on the left hand side, play the malletSTATION, and hear sounds. Depending on your audio device, you might need to set your latency lower in the Studio One options/preferences to reduce the delay between the time your mallet hits the bars and the time you hear the sound.



We hope you enjoy playing your Pearl malletSTATION with
Presonus Studio One 4 Artist!

For additional troubleshooting, please see the FAQ at www.pearlmalletstation.com.

Pearl

www.pearldrums.com

www.pearlmalletstation.com